



NUMBER	DEFINITION
1	ADJUSTMENT KNOB
2	BUTTON SWITCH FOR CHANNEL 1
3	HIROSE CONNECTOR FOR CHANNEL 1
4	POWER SWITCH
5	UP BUTTON
6	DOWN BUTTON
7	ENTER BUTTON
8	BUTTON SWITCH FOR CHANNEL 2
9	HIROSE CONNECTOR FOR CHANNEL 2
10	POWER IN
11	BNC CONNECTOR FOR ANALOG 1 (0 - 5 V)
12	BNC CONNECTOR FOR ANALOG 2 (0 - 5 V)
13	FAN EXHAUST
14	BNC CONNECTOR FOR TRIGGER 1 (5 V CMOS)
15	BNC CONNECTOR FOR TRIGGER 2 (5 V CMOS)
16	USB TYPE-B
17	SOCKET FOR EXTERNAL THERMISTOR (TSP-TH)











FOR INFORMATION ONLY
NOT FOR MANUFACTURING PURPOSES

DRAWING PROJECTION		
	NAME	DATE
DRAWN	YZ	09/JUL/2024
APPROVAL	FC	12/FEB/2025

COPYRIGHT © 2024 BY THORLABS

VALUES IN PARENTHESIS ARE CALCULATED AND MAY CONTAIN ROUNDOFF ERRORS

THORLABS
www.thorlabs.com

TEMPERATURE CONTROLLER

MATERIAL	REV
N/A	B

ITEM #	APPROX WEIGHT
TC300B	1.7 kg